



Help Text-line: 512-596-5200

EMAIL: support@urbancoopcompany.com re: Assembly Support

Shown With Optional Waterer & Feeder

VOICE: 877-741-COOP | Assembly Support ext 3

Assembly Instructions

Round-Top Walk-In Coop™



These written instructions, as provided with your purchase, will always be the latest iteration of the instructions and match the coop shipped and provide the most complete up-to-date information.


We depend on feedback about our instructions to implement changes to future versions. Please know that we value your input to that ongoing process and endeavor to produce instructions that are as effective as possible for a wide variety of customers.




Use your phones camera to read QR Code. Representation of procedure... not instructions.









Understanding these concepts / conventions will help guide you through the instructions.

- Mating edges of parts to be flush and tight (when called for) will keep measurements in tolerance as the coop grows in size.
- Having a flat area is required for the coop to assemble properly.
- We estimate about 12 man hours (a long day for 2 people) of ordinary skills to assemble. Two people are required for several steps.
- You will need a drill (preferably cordless) a tape measure and a hammer. Everything else is provided.
- Drive screws only deep enough to hold parts tight and not bury the heads too deeply as water will sit in the divots and it may cause softening of the wood and prematurely loosen screws. It will also greatly decrease your ability to easily disassemble a part if needed.
- You may end up directly driving in a screw. The brown and green screws are very aggressive and will drive with no pre-drilled hole. Keep screw entry points in the meat of the wood and not too close to edges. Screws in knots or close to edges should be pre-drilled.
- Rough Cedar may have knots, cracks or frays that are normal. We cull and cut around most imperfections we deem structurally problematic during fabrication. If you get a piece that you feel is not beautiful, please let us know so we can address your concern.
- We hand fabricated your coop with human carpenters. We work really hard to not make mistakes. On the rare occasion that we either misfabricated a part, a part was damaged in shipping, or we forgot to package a needed part, contact us and we will ship out a replacement part for you at no cost.
- We recommend dirt floors in the runs of coops. A trimmed rubber mat can be placed in the bottom of egg boxes and you may wish to put pine shavings or shredded junk mail in them. They are left wire so they can be cleaned in the event of a broken egg.



More about your new coop!

Care:

You can seal your coop if you wish. You should use a low VOC water based product. You can have color added to these products too...like painting, but it's a wood stain that lets the wood breathe. We recommend color sealing rather than painting. You paid a premium price for your coop in part to pay for the cedar. It will last outdoors in its natural state for many years, better than almost any other wood. Sealing can keep the wood from going grey. That's the main benefit. Clean wood with mild detergent and water or with a commercially available coop cleaner as needed. Glues used in all joints are completely waterproof and all metal parts are galvanized or have exterior rated coatings.

Placement:

Easy access to water/feed and clear access to doors is needed. Sunlight is not all bad, and the Galvalume roof does a good job at not transferring heat and provides shade. Sunlight does a good job at disinfecting the ground under the coop. Fifty percent (50%) or more of direct sun is preferred. Good air movement around your coop is more important than anything else. The back side should be faced North if at all possible. Remember... High ground is dry ground. For coop doors to open easily over time, the coop must be level.

Digging Predators:

The welded wire and cedar frames are stronger than almost any predator less than a bear:) so diggers are the prime nuisance. By far dogs are the most common digger. Other "wild" animals, while more rare, certainly can dig too. If you're worried about diggers, stack heavy block shaped rocks around perimeter of coop to make getting under more difficult. Better yet, bury them around the perimeter just below grade. You can also attach a strip of wire that extends out from the bottom rails, and bury below the surface of the soil. We recommend dirt in bottom of coops that has good drainage. Pine shavings, straw or shredded junk mail can be used in laying areas... but is not recommended in the main run areas.

More About Cedar:

Your coop is built from rough cut Appearance Grade North American Western Red Cedar. Our 2x2's are actually custom milled. Wood deemed defective is culled during milling, cutting and in fabrication... about 5%-10%. Knots, blemishes, fraying, coloring variations, minor surface cracking, slight warping and periodic worm marks are normal parts of rough cedar. We try to make it to where a reversible part always has a "pretty side" and take care to make the "pretty side" show on all parts. If you're unhappy with a piece of wood we fabricated into your coop, send us a picture. We want you to love every piece of your new coop.



Please Be Careful



Coop is designed to be assembled by two people of ordinary skill.



Some of the steps will need to be performed from a six foot or taller step ladder. If you are not comfortable and experienced standing on and working from a ladder you may want to get some help for those steps. Please be careful.



Any roof metal and flashing can have sharp edges. We attempt to knock of sharp corners and edges from roof metal. You must be the final determiner of sharp edges. A standard metal file from your hardware store, or metal snips, can be used to make edges to your standards. You may choose to wear a pair of work gloves while handling roof metal.



Spending the time up front to identify all the parts and lay them all out will pay off in the long run and make assembly go more smoothly. The instructions are intended to be read in page order as, the information builds in that way, then referenced during assembly. Pre-reading the instructions will help immensely.



Be careful not to get caught in coop. Children should not play in coop as the doors are not designed to allow easy exit.



Assembly Instructions
Round-Top Walk-In Coop
V-M July 2019

Warnings





Parts ID - Tool Kit





Tools & Loose Parts

QTY Description

- Gold T-25 41/2" Screws 12
- 300 Brown T-25 3" Screws
- Green T-20 1 5/8" Screws 75
- 2 **Bolt Style Gate Latch**
- 3 **Locking Clip**
- **Door Handles (if not attached)**
- 5 **Eye Bolt & Hooks**
- 100 **Neoprene Washer Roof Screws**
- 3" Door Hinges & ~24 #8 Flat Head Screws
- Bit Holder
- T-25 Bit
- **T-20 Bit**
- #2 Phillips Bit
- Window Bolts X8 (if not attached)
- 12" Stake Nails 2
- 2' Level
- Countersink Bit
- 2X Roost Access Door Fowl Weather Panels 1
- 10 **Brad Nails**
- 1 10 Feet of String
- 12 5/8 Phillips Screws for Ramps
- 3 **Snap Clips**
- **Stock Storm Panels for Roost Doors**


Optionally, your kit may have the following items and loose parts...

- 4" Pipe Waterer Sections
- **Slotted Waterer Cap**
- **Poultry Nipples**
- **Small can PVC Glue**
- Feeder Tubes & Caps

Extra 12" Stake Nails


Extra Snap Clips


Extra Hardware Related to Sun-Room Option





Parts ID - Inner Egg Box Wall








Looking From Outside




Assembly InstructionsRound-Top Walk-In Coop
V-M July 2019


or Roost Outer Wall Parts ID



Mirrored Sets







Looking From Under side



Assembly Instructions Round-Top Walk-In Coop V-M July 2019

Parts ID - Roost Roof Parts





Round-

Parts ID - Roost Parts



Parts ID - Egg Box Outer Wall







Mirrored Parts




Assembly Instructions Round-Top Walk-In Coop V-M July 2019

Parts ID - Egg Box Front & Back







Must be built on level ground.

Finished coop will weigh 800+ pounds and is not designed to be moved.





(2)

Showing back side of finished run as if you ordered the double-door option. Front and back would be the same. If you did not order double door kit, it will be solid as illustrated in the following section.

Start With The End in Mind...

The start of each section has an illustration of what you'll end up with, after that section is complete.

Section


1


Urban Coop Company


Assembly Instructions Round-Top Walk-In Coop V-M July 2019


Section 1 - Run Assembly


19

















Instructions going forward will omit some complexity as HOPEFULLY we did a good job laying some common foundations and you are catching on to the techniques and our lingo. You can always call our support hotline at 877-741-2667 or text your questions and photos to 512-596-5200.

Harvey's Hen House



Optional Sun Room panel shown if you ordered at time of coop purchase. After completing assembly, reference Sun-Room Addendum instructions.

Section 2





Assembly Instructions Round-Top Walk-In Coop V-M July 2019


Section 2 - Roost Assembly


> Page 27


◆ Standard Coop View...











Portions omitted for clarity. Install through roost access doors or from inside if you're smaller.




Section 3 - Eggbox Assembly

Assembly Instructions Round-Top Walk-In Coop V-M July 2019


Copyright ® Urban Coop Company all rights reserved.

Page 33







O Portions omitted for clarity. Screw on from back side before attaching egg box sub-assembly...











Install optional water brackets & feeders. Some panels hidden for clarity.





Optional Waterer: If you bought the waterer, you will need to rotate it downward to dump the water and then the nipples can fit through the keyhole on the top of the entry cutout. Dump into a bucket if you don't want the ground getting wet. We do this to protect the nipples and the brackets from the weight of the waterer when full.

Freeze Guard Nipples: If you have the optional Freeze Guard Nipples, they must be removed to completely remove the waterer.

Digging Predators: Due to varied terrain around the country, we do not propose only one method of protecting from digging predators. Call if you have questions and we can help you decide on the best method if it is something you are concerned about.

If You Ordered The Feeders: Feed may clog in very damp climates or when using feeds that do not have clumping agents. Usually, shaking the feeder will dislodge clogged feed. If persistent, the angled chute in the feeder can have some of the material removed from the exit opening...a little at a time until you achieve the performance you want.

Storm Panels: The Walk-In Coop™ comes stock with 2 magnetized storm panels for the roost doors. In places where there is a lot of snow or consistent sub-zero wind chill, a complete set can be ordered as an option. Magnets on optional set require installation by the consumer to protect them during shipping.

See our web site for options to keep water from freezing in the optional waterer.



Assembly Instructions Round-Top Walk-In Coop V-M July 2019